

User Manual: Fire-Boltt Ninja Call Pro Plus

Introduction

The Fire-Boltt Ninja Call Pro Plus is a feature-packed smartwatch designed to provide seamless connectivity, advanced fitness tracking, and stylish wearability. This manual will guide you through setup, usage, and maintenance.

Features

- **Display:** 1.83-inch HD full-touch screen with high resolution.
 - **Bluetooth Calling:** Make and receive calls directly from your wrist.
 - **Fitness Tracking:** Heart rate monitoring, sleep tracking, SpO2 measurement, and multiple sports modes.
 - **Smart Notifications:** Alerts for messages, calls, and apps.
 - **Battery Life:** Long-lasting battery for days of use on a single charge.
 - **Customization:** Interchangeable straps and various watch faces.
-

Package Contents

1. Fire-Boltt Ninja Call Pro Plus Smartwatch
 2. Magnetic Charging Cable
 3. User Manual
 4. Warranty Card
-

Getting Started

1. **Charge Your Watch:** Use the magnetic charging cable provided to charge your watch fully before first use.
 2. **Power On/Off:** Press and hold the side button for 3 seconds.
 3. **Pairing:**
 - Download the companion app (available on iOS and Android).
 - Enable Bluetooth on your smartphone and connect to the watch via the app.
 4. **Customization:**
 - Access settings to choose watch faces and enable fitness modes.
-

Product Care

- Avoid contact with water unless specified as water-resistant.
- Clean the watch regularly with a soft, dry cloth.

- Do not expose the watch to extreme temperatures or direct sunlight for extended periods.